

**Switch Center Quick Install Instructions:**

1. Download the installation file (Linux or Windows) appropriate for your environment.
2. Download and review the *Release Notes* and the *User Guide*, for installation requirements and additional details.
3. Switch Center uses the following network ports on the server on which it is installed, so ensure no other application is using them:
 - Port 40080 for HTTP
 - Port 40443 for HTTPs
 - Port 40999 for RMI Service
 - Port 162 for SNMP trap reception
 - Port 514 for syslog reception
4. Perform one of the following procedures, depending on your operating system:

Windows only:

- a) Double-click the installation file, it will be one of:
 - 8.1.x.x_install_win.exe (licensed version)
 - 8.1.x.x_install_win_eval.exe (evaluation version)
- b) An installation wizard guides you through the installation process.
- c) When done, you can optionally check the InstallAnywhere installation log file for errors. It will be located in the C:\Program Files\IBM\SNSC directory named:
_System_Networking_Switch_Center_Install_<date/time>.log

Linux only:

- a) Run the installation file under root privilege, it will be one of:
 - # ./8.1.x.x_install_lin.bin (licensed version)
 - # ./8.1.x.x_install_lin_eval.bin (evaluation version)
 - b) The Linux installer is a self-extracting shell script, which installs Switch Center under the following directory: /opt/ibm/SNSC
 - c) When done, you can optionally check the InstallAnywhere installation log file for errors. It will be located in the /opt/ibm/SNSC/_System_Networking_Switch_Center_installation/Logs directory named:
System_Networking_Switch_Center_Install_<date/time>.log
5. The Switch Center services will start automatically after a few minutes.
 6. On Windows, a program group under “IBM” will be created that allows management of the Switch Center services and launching to the application.
 7. For Linux, simply launch a browser and log into Switch Center as administrator.
`http://<hostname>:40080/snsc`, where <hostname> is the DNS name or IP address of the server where Switch Center is installed. Use `admin` as both the username and password for administrator login.

© Copyright Lenovo Corp. 2015-2017

Portions © Copyright IBM Corporation 2014.

LIMITED AND RESTRICTED RIGHTS NOTICE: If data or software is delivered pursuant a General Services Administration “GSA” contract, use, reproduction, or disclosure is subject to restrictions set forth in Contract No. GS-35F-05925.

Lenovo and the Lenovo logo are trademarks of Lenovo in the United States, other countries, or both.